

Figure 1

1/9
AUS9-2000-0555-US1





Figure 2

2/9

AUS9-2000-0555-US1







Figure 3

server

Client







Figure 5

5/9

AUS9-2000-0555-US1



Navigation Device

600

Figure 6

5/9

AUS9-2000-0555-US1

Figure 7

6/9
AUS9-2000-0555-US1

700		
Field name 702	Field length 704	Field 706

Figure 8

6/9
AUS9-2000-0555-US1




Figure 9

7/9
AUS9-2000-0555-US1




Figure 10

8/9
AUS9-2000-055-US1




Figure 11

9/9
AUS9-2000-055-US1

